

Index

A

- adding MIRAN to Meridian 1
 - system options, 41
- administration
 - card level, 84
 - MIRAN, 74, 79
- altering assigned message, 84
- analog
 - channel passthrough, 54
- analog port, 4, 185
 - backplane signals, 185
- analog sources
 - external, 36
- announcements
 - emergency, 163
 - for different times of day, 161
- application
 - examples, 37
 - music, 37
 - RAN, 37
 - RAN and MOH, 37
- architecture
 - design characteristics, 7
 - hardware, 12
 - MIRAN, 7
 - software, 10
- Assign Message screen, 118
- audio device connection, 53
- audio jack, 16

B

- backplane pinouts, 185, 186
- backplane signals, 186

- Backup Configuration screen, 127
- backup to PCMCIA card, 89
- backup to PCMCIA Flash, 89

C

- capacity
 - options (table), 9
 - voice storage, 32
- capacity expansion, 9
- card installation
 - into Option 11 system, 60
- Card LAN, 20
- card replacement for MIRAN, 174
- CE-MUX signals, 21
- checksum byte in messages, 26
- Clear Assignments screen, 121
- codes
 - MIRAN hex codes, 178
- command files, 85
- Commands, 169
- commands
 - Batch File commands, 160
 - file commands, 155
 - for MIRAN OA&M access, 147
 - message commands, 152
 - miscellaneous commands, 158
 - syntax, 151
- commands summary table, 148
- compatibility, systems, 30
- configuration
 - restore, 90

configuring

- MIRAN characteristics, 71
- MIRAN trunk data block, 71
- Option 11 pass-through, 72
- sound recording, 177
- terminal, 74
- terminal parameters, 109

connecting

- audio device to MDF, 54
- audio device to MIRAN faceplate, 54
- external audio device, 53
- multiple MIRAN cards, 56
- terminal, 50
- terminal to MDF, 51
- terminal to MIRAN, 50

connecting MIRAN to trunks (diagram), 46

connection to music source, 16

connections, backplane, 18

connectors

- MDF cable, 181
- MIRAN interface, 180

Convert Message screen, 124

converter DC/DC, 34

Copy Assignments screen, 120

Copy File screen, 135

cross-connect diagram, VPS, 46

cross-connect ports

- pinouts, 186

D

DC/DC converter, 34

Delete File screen, 136

description, MIRAN, 4

device

- security, 28

diagnostic self-test, 22

diagnostic self-tests, 165

display

- codes, 166
- faceplate seven-segment, 166

Distributor Level Password screen, 146

DS-30X interface, 20

E

electrical

- power (tables), 34
- regulatory standards
 - electro-magnetic compatibility, 192
 - electro-magnetic immunity, 193
 - safety, 191

electrical regulatory standards

- electro-magnetic emissions, 192

electro-magnetic compatibility, 192

electro-magnetic emissions, 192

electro-magnetic immunity, 193

emergency messages, setting up, 163

engineering

- guidelines, 30
- RAN and MOH, 37

error detection in messages, 26

examples

- RAN application, 37

expanding capacity, 9

expansion, 9

external music recording, 84

F

faceplate

- description, 16
- diagram, 17
- LED, 18
- mini-DIN connector signals (table), 180

fault isolation and correction

- MIRAN, 170, 171

File Commands menu, 132

File Display screen, 134

Flash memory

- increasing voice storage, 24, 88

flowcharts, OA&M telephone set-based interface

- delete menu flowchart, 104
- record menu, 103
- record menu flowchart, 102
- setup menu flowchart, 105

functions monitoring, 23

G

- ground
 - analog, 34
 - frame, 34
 - logic, 34
- ground requirements, 33
- guidelines
 - engineering, 30

H

- hard reset, 21
- hex codes
 - faceplate display, 18, 178
- hot insert of PCMCIA, 83

I

- ID
 - security device, 76
- identification
 - security, 29
- initialization
 - BIOS, 22
 - hardware, 22
- inspecting equipment, 42
- installation
 - MIRAN, 47
 - RAN application of, 78
- installing MIRAN cards, 48
- interface, analog ports, 19
- interfaces, analog ports, 185
- internal music recording, 84
- inventorying equipment, 43
- IPE
 - MIRAN card slot location, 43
- IPE module
 - location of MIRAN (diagram), 49
 - terminal connection, 50

J

- jack
 - audio input/output, 16

K

- keycode
 - security, 30, 77
- Keycode Entry screen, 139

L

- LAN
 - administration of, 80
 - connection at the MDF, 58
 - messaging, 26
 - multiple MIRAN connection, 56
 - transit delays, 27
- Last Assignment screen, 119
- LED on faceplate, 18
- List Files menu, 133
- login on telephone set, 94
- logon screen, 110

M

- Main Menu, 173
- maintenance
 - hex display, 18
 - history file, 170
 - port, 4, 18
- Maintenance and Diagnostics menu, 143
- MDF wiring, 43
- memory
 - PCMCIA Flash, 4
 - upgrades for RAN application, 85
- menu
 - File Commands, 132
 - List Files, 133
 - Maintenance and Diagnostics, 143
 - Message Commands, 117
 - MIRAN Administration, 131
 - RAN Administration, 116
 - telephone set-based OA&M, 94
- Meridian 1
 - maintenance of MIRAN, 169
- Message Commands menu, 117
- message transmission in LAN, 26

messages

- for different times of day, 161
- for emergencies, 163

messaging

- LAN, 26

MIRAN

- administration of, 79
- architecture, 7
- backplane connections, 18
- capacity expansion, 9
- capacity impact, 9
- capacity options, 9
- clock setup, 80
- description of, 3, 4
- faceplate, 16
- location in IPE module (diagram), 49
- maintenance of, 169
- mechanical characteristics, 13
- mechanical interface, 13
- message exchange, 27
- multiple, 25
- port expansion, 9
- power requirements, 33
- purpose of, 1
- recording features, 6
- regulatory standards, 191
- security, 74
- storage capacity features, 6
- upgrade, 23

MIRAN administration

- using terminal, 80

MIRAN Administration menu, 131

MIRAN clock

- setting, 80

MMI (Man-Machine Interface)

- example, 97

mode

- pass-through for Option 11, 72

modem

- configuration, 187
- connecting to faceplate, 51
- connecting to I/O panel, 53

MOH

- conference loop, 67
- route, 68

monitoring

- alarm, 23
- built-in, 23
- error, 23
- messages, 23
- sanity, 23, 169

Move File screen, 138

multi cross-connect

- at the MDF, 44
- channels, 33
- characteristics, 33

multi cross-connect ports, 9, 186

multi-channel RAN, 65

music-on-hold

- activation, 67
- MOH, 3
- route selection, 67

N

NTAG36 MIRAN card, 3

O

OA&M

telephone set-based interface, 78, 93

- delete menu flowchart, 104

- description, 92

- MMI example, 97

- password flowchart, 100

- port number assignments, 95

- record menu flowchart, 103

- voice prompts, 98

terminal-based, 109

- interface, 79

- menu system, 113, 172

- operational statistics display, 126

terminal-based access, 116

- OA&M access
 - telephone set-based, 36
 - terminal configuration, 74
- OA&M Access Configuration screen, 142
- OA&M command set, 147
- OA&M commands syntax, 151
- one-to-one ports, 9
- Operational Statistics screen, 126
- Option 11
 - MIRAN installation, 60
 - terminal connection, 60
- options
 - port capacity, 31
- overview
 - installation, 41
 - maintenance, 165

P

- passthrough
 - analog, 54
- password
 - user, 75
- PCMCIA
 - cards for RAN upgrades, 86, 87
 - dual-type socket, 18, 19
- PCMCIA Flash, 4
- pinout tables
 - analog port backplane, 185
 - faceplate mini-DIN connector, 180
 - multi cross-connect ports, 186, 187
- pinouts
 - interface connectors, 180
- Play Message screen, 123
- Playback Levels screen, 129
- port
 - analog, 19
 - capacity options, 31
 - MIRAN expansion, 9

ports

- accessing RS-232 serial, 19, 180
- analog, 185
- multi cross-connect, 9, 33, 186
- one-to-one, 9
- RS-232, 19, 180

R

RAN

- activation, 62
- continuous delayed, 63
- continuous immediate, 63
- examples, 37
- immediate start/stop, 66
- multi-channel start/stop, 65
- route selection, 62
- RAN Administration menu
 - terminal-based access, 116
- RAN application
 - command summary, 148
 - emergency messages, 163
 - installation, 78
 - Main Menu, 113, 173
 - menu system, 107, 165, 172
 - playing messages at specified times, 161
 - recording announcements/music, 81
 - security, 74
 - special features, 161
 - telephone set-based OA&M, 91
 - upgrades, 85
- RAN installation
 - real time clock setup, 78
- RAN modes, 32
- Record Messages screen, 122
- recorded announcement
 - RAN, 3
- recording
 - PC-based RAN, music, 82
 - tape or CD player, 83
 - telephone set-based, 83
- recording announcements/music, 81
- recording features, 6

recordings

- external, 84
- internal, 84
- PC-based, 82
- telephone set-based MMI, 80

reliability, 189

Rename File screen, 137

replacing old message, 84

reset card procedure, 172

reset switch, 18

reset, soft, 22

restore configuration, 90

Restore Configuration screen, 128

RS-232

- maintenance port, 18

- ports, accessing, 180

Run Batch Files menu, 130

S

safety regulations (table), 191

screen

- Assign Message, 118
- Backup Configuration, 127
- Clear Assignments, 121
- Convert Message, 124
- Copy Assignments, 120
- Copy File, 135
- Delete File, 136
- Distributor Level Password, 146
- File Commands, 132
- File Display, 134
- Keycode Entry, 139
- Last Assignment, 119
- Last Files, 133
- Maintenance and Diagnostics, 143
- MIRAN Administration, 131
- Move File, 138
- OA&M Access Configuration, 142
- Play Message, 123
- Playback Levels, 129
- Record Messages, 122
- Rename File, 137
- Restore Configuration, 128

screen (cont)

- Run Batch Files, 130
- Software Upgrade, 140
- status screen, 111
- System Information, 141
- Top Level Password, 144
- User Level Password, 145

security

- distributor password, 75
- ID, 29
- keycode, 30, 77
- RAN application, 74
- security device, 28
- software, 28, 75
- user password, 75

security device, 76

security ID, 77

self-test

- diagnostic, 22, 167
- sequence, 167

setting up

- telephone set-based OA&M access, 112

signals

- backplane, 185
- DS-30X, 3
- faceplate mini-DIN connector, 180
- multi cross-connect, 186

socket

- Type II, dual type (PCMCIA), 18

soft reset, 22

software

- security, 28, 75
- upgrade for RAN, 87

Software Upgrade screen, 140

sound recording

- voice messages, 177

special features

- emergency messages, 163
- playing messages at specified times, 161

standards, regulatory, 191

status screen

- terminal OA&M, 111

- switchover
 - analog to internal, 54
- system compatibility, 30
- System Information display, 141

T

- telephone set-based OA&M
 - assigning a message, 95
 - Delete Menu flowchart, 104
 - deleting a message, 96
 - flowcharts, 99
 - Main Menu flowchart, 101
 - menu operation, 94
 - Password Entry flowchart, 100
 - playing a message, 96
 - playing security ID, 97
 - Record Menu flowchart, 102
 - recording a message, 96
 - selecting a message, 96
 - Setup Menu flowchart, 105
- telephone set-based OA&M access
 - setup, 112
- telephone set-based recordings, 80
- terminal
 - connection at the faceplate, 50
 - emulation, 35
 - VT100, 35
- terminal-based OA&M access
 - Main Menu, 113
 - maintenance and diagnostics, 143
 - MIRAN Administration, 131
 - MIRAN commands, 147
 - RAN Administration, 116
- tests
 - diagnostic self-tests, 165
- Top Level Password screen, 144
- Type II socket, dual type, 18, 19

U

- Universal Trunk Card emulation, 10
- unpacking equipment, 42

- upgrade
 - MIRAN, 23
 - PCMCIA card, 24
- upgrades
 - PCMCIA (diagrams), 88, 90
 - PCMCIA, using, 86
 - RAN application, 85
 - software, 87
 - voice storage, 24, 88
- User Level Password screen, 145

V

- voice prompts for OA&M, 98
- voice storage upgrade, 24

W

- wiring to the MDF, 43

Meridian 1

Meridian Integrated RAN

Description, installation, and
operation

P0866165

© 1995 Northern Telecom

All rights reserved

Information is subject to change without notice.

Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Publication number: 553-3001-112

Document release: Standard 1.00

Date: April 1997

Printed in the United States of America